

XT+ Releasing Control Unit Operating Instructions



Contents

Contents	2
User Access Levels	4
Standby Mode	4
Access Level 2	5
Access Level 3	8
Unit Tests	10
General Information	12
Operating Instructions	12
Inspecting Batteries	12
Replacing Standby Batteries	12
Related Documentation	12
Contact Information	14
Emergency Contact	14
Service Contact	15

USER ACCESS LEVELS

Standby Mode

Standby mode indicates that the Enable Keyswitch has not been activated. The LCD screen will display the following:



MAN&AUTO

Specific functions are restricted when operating the unit in the standby, however this level allows users to perform simple tests. It also provides options for testing LED indicators of the fascia as well as color composition of the LCD panel GUI. Refer to [Unit Tests](#) for specific feature details.

Access Level 2

Insert the key in the Enable Access keyswitch and turn it to the right to obtain Access Level 2. XT+ releasing modules will ignore Enable Access commands from the Elite RS panel and will enter access level 2 only when their own Enable Access switch is operated. When the Enable Access keyswitch is turned, the XT+ LCD menu will display:

```
Access Level 2 →
ENTER for Menu
```

```
Disable
Exting. Release?
```

Press **Enter** to disable the extinguishant release outputs. The Disablement and Supervisory LEDs will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP.

```
Enable
Exting. Release?
```

Press **Enter** to re-enable the outputs and restore the Disablement and Supervisory conditions.

```
Disable
Manual Release?
```

Press **Enter** to disable the manual release input. The Disablement LED will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP.

```
Enable
Manual Release?
```

Press **Enter** to re-enable the input and restore the Disablement condition.

```
Disable
Stage 1 Output?
```

Press **Enter** to disable the 1st stage relay output. The Disablement LED will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP.

Enable
Stage 1 Output?

Press **Enter** to re-enable the output and restore the Disablement condition.

Disable
Stage 2 Output?

Press **Enter** to disable the 2nd stage relay output. The Disablement LED will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP. The display will show:

Enable
Stage 2 Output?

Press **Enter** to re-enable the output and restore the Disablement condition.

Disable
Released Output?

Press **Enter** to disable the released output. The Disablement LED will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP. The display will show:

Enable
Released Output?

Press **Enter** to re-enable the output and restore the Disablement condition.

Disable
Extract Output?

Press **Enter** to disable the extract output. The Disablement LED will illuminate and the buzzers will sound on the XT+ module and the Elite RS FACP. The display will show:

Enable
Extract Output?

Press **Enter** to re-enable the output and restore the Disablement condition.

Turn ON
Extract Output?

Press **Enter** to turn on the extract output. The buzzer will sound on the Elite RS FACP. The display will show:

Turn OFF
Extract Output?

Press **Enter** to re-enable the output and restore the Disablement condition.

Select Reserve
Exting. Output?

Press **Enter** to select the Reserve output. When the Reserve output is selected, the Reserve Cylinders LED will be illuminated and the LCD will display the following:

Select Main
Exting. Output?

Press **Enter** to select the Main output.

Access Level 3

To enter Access Level 3, turn the Enable Access keyswitch and turn the Write Enable switch to the on (left) position. The following actions are available in Access Level 3:

- Set the extinguishing monitoring level.
- Display the number of updates to the module's configuration
- Change the monitoring level of the extinguishing outputs it is necessary to enter access level 3.

To enter Access Level 3, turn the Enable Controls keyswitch on and slide the **Write Enable** switch to the on position (left). The # represents the number of configuration updates made to the XT+ module.

```
AL3 Updates = #  
ENTER for Menu
```

Press **Enter**, then **(+)** until the LCD displays:

```
Exting. O/P 1  
Level = XXX
```

The XXX displayed here is the PREVIOUS (factory) level to which the monitoring level had been set.

Press **Enter**. The LCD will now show:


```
Exting. O/P 1  
Level = XXX ?
```

The XXX shown here is the CURRENT monitoring level detected on the extinguishing output. Press **Enter** to store that level. The circuit characteristics are then learned by the unit and a trouble will occur if these change.

Press **(+)** to display and set the monitoring level for output 2 in the same way as output 1.

UNIT TESTS

To perform a lamp, display, and buzzer test from Standby Mode or Access Level 2, press and hold the **Exit** button. After several seconds, the following should occur:

- all LEDs will illuminate
- the buzzer buzzes steadily
- the LCD will display the following:



GENERAL INFORMATION

Operating Instructions

These operating instructions shall be placed near the panel.

Inspecting Batteries

Inspect the standby batteries annually to determine the connection integrity to the XT+ Releasing Control Unit. The fire control panel contains sealed lead acid batteries to provide standby power in the event of power failure. The standby batteries have a life expectancy of 3 to 5 years. Test the standby batteries annually in accordance with the battery manufacturer's recommendations to determine their suitability for continued standby operation.

Replacing Standby Batteries

Replace standby batteries when the service period reaches 3 to 5 years or when the low battery message is present on LCD display. The standard size cabinet of the panel accepts battery sizes up to 28 Ah. Batteries larger than 28 Ah may be mounted remotely in a UL listed battery cabinet. Batteries smaller than 28 Ah do not require special cabinet mounting considerations. The power supply charges up to 60 Ah.

Related Documentation

The following documents shall be used to provide additional information for installing and operating the XT+ Releasing Control Unit:

- XT+ Releasing Control Unit Installation Guide (MAN-1252KE)
- XT+ Releasing Control Unit Wiring Diagram (MAN-1255KE)

CONTACT INFORMATION

Emergency Contact

Contact the company or individual responsible for providing assistance in the event of an emergency. In the event of an emergency, notify:

Name

Company

Primary Telephone

Secondary Telephone

Cell Phone

Address

City

State

Service Contact

Contact the company or individual responsible for providing service:

Name

Company

Primary Telephone

Secondary Telephone

Cell Phone

Address

City

State