

AMS Manual Pull Station

VF3031-10, VF3032-10, and VF3029-10



VF3031-10



VF3032-10



VF3029-10

Standard Features

- Addressable integrated design
- All metal construction
- Single and dual action models available
- Extremely easy to operate
- Bi-colored status LED indicates Standby and Alarm conditions
- Address is programmable in EEPROM
- Address can be programmed when installed
- Key lock or hex key lock models available
- Enclosed switch with glass rod (included)
- Terminals accept up to 14AWG wire
- Surface mount back box available

Ordering Codes

VF3031-10	Single action with Hex Screw Lock
VF3032-10	Single action with Hex Key Lock
VF3029-10	Dual action with Key Lock

Product Overview

The AMS series of addressable manual pull stations provide a fast and practical means of manually initiating a fire alarm signal. Both single action and dual action manual pull stations are available. Resetting of the pull station requires either a Cat 30 key or a 1/8" hex key (depending upon the model used).

An alarm condition is actuated by pulling down on the handle of the VF3031-10 and VF3032-10 single action models. On the dual action model VF3029-10 the Lift and Pull cover must be lifted before pulling down on the pull station handle. Once the pull station is activated, the handle cannot be put back into a normal standby condition without using the key operated reset feature.

The AMS series is electronically addressable and includes a bi-colored status LED. The LED blinks green indicating normal communication with the DCP compatible SLC loop. When an alarm condition is actuated by pulling the handle, the LED will latch Red to indicate the alarm condition.



Engineering Specification

Manual pull stations shall be VES addressable AMS series single or dual action models, VF3031-10, VF3032-10, or VF3029-10. Models shall be made of 14 AWG CRS and painted with Red enamel. The words Fire Alarm shall be in a contrasting color and be embossed text 1/2" tall. The electronics shall be fully integrated into the manual pull station requiring only connection to the SLC loop of the control panel. Programming of the manual pull station address must be possible with the manual pull station fully installed.

Manual pull stations shall be Underwriters Laboratories Inc. Listed and be installed within the limits defined in the Americans With Disabilities Act.

Technical Specifications

Operating Voltage	17-41 VDC
Average Consumption	550 μ A (typical) 660 μ A (standard)
Ambient Temperature	32°F to 120°F
Maximum Humidity	90% non-condensing
Dimensions	3.4"W x 4.8"H x 2.0"D
Mounting	Single gang or 4" square electrical box